

UT321/322/323/325
Operating Manual



Digital Thermometers

Overview

The Uni-Trend Model UT321, UT322, UT323 and UT325 Thermometers (the thermometer) are microprocessor-based, digital thermometers designed to use external J-, K-, T-, E-, R-, S- and N- type thermocouples (temperature probes) as temperature sensors.

- UT321: single input(T1), suitable for K-, J-, T- and E- type thermocouples
- UT322: dual input(T1,T2), suitable for K-, J-, T- and E- type thermocouples
- UT323: single input(T1), suitable for K-, J-, T-, E-, R-, S- and N- type thermocouples. Equipped with over limit alarm, over limit signal output and user self-debug features.
- UT325: dual input(T1,T2), suitable for K-, J-, T-, E-, R-, S- and N- type thermocouples. Equipped with over limit alarm, over limit signal output and user self-debug features.

Safety Information

Use the thermometer only as specified in this manual. Otherwise, the protection provided by the meter may be impaired.

Refer to safety information in Table 1 and the international symbols in Table 2.

Table 1. Safety Information

Warning
A warning identified conditions and actions that pose hazards to the user. To avoid electrical shock or personal injury, follow these guidelines:

- Before using the thermometer inspect the case. Do not use the thermometer if it appears damaged. Look for cracks or missing plastic. Pay particular attention to the insulation around the connectors.
- Disconnect the thermocouple(s) from the thermometer before opening the case.
- Replace the batteries as soon as the battery indicator (🔋) appears. The possibility of false readings can lead to personal injury.
- Do not use the thermometer if it operates abnormally. Protection may be impaired. When in doubt, have the thermometer serviced.
- Do not operate the thermometer around explosive gas, vapor, or dust.
- Do not apply more than the rated voltage, as marked on the thermometer (30V), between the thermocouple(s), or between any thermocouple and earth ground.
- When potential differences are anticipated between the thermocouples, use electrically insulated thermocouples.
- When servicing the thermometer, use only specified replacement parts.
- Do not use the thermometer with any part of the case or cover removed.

Caution
A caution identifies conditions and actions that may damage the meter or the equipment under test.

- Use the proper thermocouples, function, and the range of your thermometer.
- When carrying two thermocouples measurement, make sure there are no potential differences between two thermocouples.
- Do not attempt to recharge the battery.
- Match the + and - polarities of the battery with the battery case.

Table 2. International Symbols

| | |
|--|--|
| | Refer to the manual for information about this feature |
| | Complies with European Union directives |
| | Battery |

Get Acquainted with Your Thermometer

Unless otherwise specified, all the descriptions apply to all Models of UT321, UT322, UT323 and UT325.

To become familiar with the thermometer, study the following:

- Figure 1 and Table 3 for components;
- Figure 2 and Table 4 for LCD display;
- Figure 3-a and 3-b and Table 5 for button functions;

Components




Figure 1. Components

Table 3. Components

| | |
|---|---|
| ① | Display |
| ② | Buttons |
| ③ | Thermocouple T1 input |
| ④ | Thermocouple T2 input (UT323 and UT325 only) |
| ⑤ | USB Port |
| ⑥ | SIGN Port - Over Limit Signal Output (UT323 and UT325 only) |
| ⑦ | NTC |
| ⑧ | Battery Door |
| ⑨ | 9V battery (6F22) |

LCD Display




Figure 2. Display LCD Display

Table 4. LCD Display

| | |
|---|---|
| ① | Setup is in progress when the icon blinks |
| ② | Display readings of maximum, minimum and average |
| ③ | Data Transferring is in progress |
| ④ | Logged readings are displayed when the icon blinks |
| ⑤ | Low battery indicator. Replace the battery |
| ⑥ | The thermocouple type |
| ⑦ | The temperature units |
| ⑧ | Secondary Display 2 |
| ⑨ | Under Calibration mode when the icon blinks. The displayed reading is fixed. |
| ⑩ | Secondary Display 1 |
| ⑪ | The thermocouple measurement includes an offset. See "Changing Setup Options" |
| ⑫ | Readings are being logged when the icon blinks |
| ⑬ | Primary Display |
| ⑭ | Data hold function is active. |
| | The symbol of display backlight |

Buttons




Figure 3-a UT321 and UT323 Keypad




Figure 3-b UT322 and UT325 Keypad

Table 5. Buttons

| | |
|-------------------------------|--|
| | Press to turn the thermometer on or off |
| | Press to turn the display backlight on and off. |
| HOLD | Press to freeze or unfreeze the displayed readings |
| °C °F K | Press to switch between Celsius (°C), Fahrenheit(°F), and Kelvin (K) |
| MAX MIN | Press to step through the maximum, minimum, and average readings. Press and hold to exit this function. |
| TYPE (UT321/UT323) | Press to step through K-, J-, T-, E- (R-, S-, N-) type thermocouple. |
| T1 T2 (UT322/UT325) | Press to select and show T1, T2 and T1-T2 (differential temperature measurement) in the primary or secondary display 1 |
| SEND | Press to enter USB mode and the USB icon blinks. Press again to exit USB mode. |
| STORE | Press to start or stop logging. (See "Using Memory - Starting and Stopping Logging".) |
| RECALL | Press to show logged readings Press again to stop. |

| | |
|--------------|--|
| SETUP | Press to start or exit Setup. Press to scroll the Setup option you want to change (See "Changing Setup Options") |
| | After entering the Setup mode, press to increase the displayed setting. (See "Changing Setup Options") |
| | After entering the Setup mode, press to decrease the displayed setting. (See "Changing Setup Options") |
| ENTER | Confirm button. (See "Changing Setup Options") |

Using the Thermometer

- 1) Plug the thermocouple(s) into the input connector(s).
- 2) Press the power button to turn on the thermometer.
- 3) Set the type of thermocouple(s) to be the same with the one plugged into the input connector(s).

If no thermocouple is plugged into the selected input terminal or the thermocouple is "open" or the over-range positive deviation is too big, the display shows "-----".

Changing Setup Options

- Use Setup to change the following settings:
- Logging interval → Thermocouple type → Offset (T1) → Offset (T2) (UT322 and UT325 only) → Sleep Mode → Line Frequency → Time (S-T) → Low Limit Alarm (Lo) (UT323 and UT325 only) → High Limit Alarm (Hi) (UT323 and UT325 only) → Over Limit Signal Output (SI) ON/OFF → (UT323 and UT325 only) Normal Temperature Compensation (NTC) ON/OFF → DEBUG ON/OFF (UT323 and UT325 only) → Save setting and return to normal measurement mode.

Entering and Exiting Setup

When the thermometer is in Setup mode, the display shows and blinks SETUP.

- Press **SETUP** to start or exit Setup.
- Press **SETUP** to scroll through the Setup options you want to change.

Changing the Logging Interval

The logging interval determines how often the thermocouple stores logged readings in memory. You choose the length of the logging interval. See "Using Memory".

Press **SETUP** until the display shows INTERVAL.

The thermometer stores logged readings at the end of each logging interval. You can select a logging interval by pressing or . Holding down or causes the number to change more quickly. The maximum interval is 59:59 and the minimum interval is 00:00. When the logging interval is 00:00, you need to store the readings manually as the auto store feature will be disabled.

Changing the Thermocouple Type

1. Press **SETUP** until the display shows TYPE.
2. Press or to select the thermocouple type you want including K-, J-, E- type (UT323 and UT325 have extra R-, S- and N- type, UT321/UT325 can use TYPE button to change directly).

Changing the Offset (T1)

1. Press **SETUP** until the display shows OFFSET and T1
2. Press or to change the offset value. The offset range is -6~6.

Changing the Offset (T2)

1. Press **SETUP** until the display shows OFFSET and T2
2. Press or to change the offset value. The offset range is -6~6.

Sleep Mode

1. Press **SETUP** until the display shows SLP.
2. Press or to change until the desired sleep time is obtained. it is between 5~60 minutes.
3. Holding down or causes the time to change more quickly.
4. When the sleep mode time is less than 5 minutes, the display shows OFF which means disabling the sleep mode.

Changing the Line Frequency

1. Press **SETUP** until the display shows LINE.
2. Press or to select 60Hz or 50Hz.

Setting the Time

1. Press **SETUP** until the display shows S-T.
2. Press **ENTER** to toggle between time format "h:m" and "m:s".
3. Press or until the display shows the correct time. The time is 24-hour format.
4. Holding down or causes the number to change more quickly.
5. If you don't change this option, it means the time that the meter has run through currently.
6. The system counts the time when the user turns on the thermometer. It will be automatically cleared once the Thermometer is dis-energized.

Setting the Low Limit Alarm (Lo) (Only UT323 and UT325)

1. Press **SETUP** until the display shows Lo.
2. Press or until the display shows the correct low limit alarm.
3. Holding down or causes the number to change more quickly
4. Press **ENTER** to turn the low limit alarm off, the display shows OFF. Press **ENTER** again to turn the low limit alarm on, the display shows the low limit alarm reading.
5. When the tested temperature is over the limit, the thermometer beeps
6. The Min.value for low alarm is the lower limit value of measuring range of the applied thermocouple.
7. The Max. value for low alarm is the setting high alarm limit value if high alarm is enabled (if still higher than high alarm limit value, Max. value=High Alarm Limit Value-1), otherwise this Max. value is the upper limit value of measuring range of the applied thermocouple.

For example:

- The Min. value of the low alarm of K type is -200°C.
- The Max. value of the low alarm of K type is either High Alarm Limit Value-1 or +1372°C

The table below shows the measuring range of each type of thermocouple

| |
|---|
| K type: -200.0°C to +1372°C (-328.0 °F to +2501 °F) |
| J type: -210.0°C to +1200°C (-346.0 °F to +2192 °F) |
| T type: -250.0°C to +400.0°C (-418.0 °F to +752.0 °F) |
| E type: -150.0°C to +1000°C (-238.0 °F to +1832 °F) |

Setting the High Limit Alarm (Hi) (Only UT323 and UT325)

1. Press **SETUP** until the display shows Hi..
2. Press **▲** or **▼** until the display shows the correct high limit alarm.
3. Holding down **▲** or **▼** causes the number to change more quickly
4. Press **ENTER** to turn the high limit alarm off, the display shows OFF. Press **ENTER** again to turn the high limit alarm on, the display shows the high limit alarm reading.
5. When the tested temperature is over the limit, the thermometer beeps
6. The Max.value for high alarm is the upper limit value of measuring range of the applied thermocouple.
7. The Min. value for high alarm is the setting low alarm limit value if low alarm is enabled (if still less than the low alarm limit value, Min. Value=Low Alarm Limit Value+1), otherwise this Min. value is the lower limit value of measuring range of the applied thermocouple.

For example:

- The Max. value of the high alarm of K type is +1372°C.
- The Min.value of the high alarm of K type is either Low Alarm Limit Value+1 or -200°C.

The table below shows the measuring range of each type of thermocouple

| |
|---|
| K type: -200.0°C to +1372°C (-328.0°F to +2501°F) |
| J type: -210.0°C to +1200°C (-346.0°F to +2192°F) |
| T type: -250.0°C to +400.0°C (-418.0°F to +752.0°F) |
| E type: -150.0°C to +1000°C (-238.0°F to +1832°F) |

Enabling or Disabling Over Limit Signal Output (Only UT323 and UT325)

1. Press **SETUP** until the display shows SI.
2. Press **▲** or **▼** to turn the over limit signal output on or off. The display shows on or oFF.
3. With High/Low Limit Alarm set up and Over Limit Signal Output turned on already, the SIGN port of the thermometer will output the corresponding signal if the tested temperature is over or under the high or low limit. When the tested temperature is over the high limit, the SIGN port will output the high electric level signal. When the tested temperature is under the low limit, the SIGN port will output around 10Hz pulse signal.

Enabling or Disabling Normal Temperature Compensation (NTC)

1. Press **SETUP** until the display shows NTC.
2. Press **▲** or **▼** to turn normal temperature compensation on or off. The display shows On or Off. It defaults to ON status at power-on.

Enabling or Disabling Debug (Only UT323 and UT325)

1. Press **SETUP** until the display shows DEBUG.
2. Press **▲** or **▼** to turn Debug on or off. The display shows on or oFF. The thermometer defaults to OFF status.
3. You can self-debug the thermometer when the Debug feature is turned on. (Refer to Measuring Temperatures – Debug)

Measuring Temperatures

Connecting a Thermocouple

Thermocouples are color-coded based on the North American ANSI Colour Code:

| Type | Colour | Type | Colour |
|------|--------|------|--------|
| J | Black | R | Green |
| K | Yellow | S | Green |
| T | Blue | N | Orange |
| E | Purple | | |

1. Plug a thermocouple into the input connector(s).
2. Set the same thermocouple type in the thermometer.
To change the thermocouple type, see "Changing Setup Options".

Displaying Temperatures

1. Press °C °FK to select the correct temperature unit.
2. Hold or attach the thermocouple(s) to the measured location.
The temperature shows in the selected unit on LCD.

Holding the Displayed Temperatures

1. Press **HOLD** to freeze the readings on the display. The display shows HOLD.
2. Press **HOLD** again to turn off the HOLD function.

Turning on and off display backlight

1. Under temperature measurement mode, press  to turn the display backlight on.
2. Press  again to turn off the display backlight. The display backlight will not turn automatically off.

Viewing the MIN, MAX, and AVG Readings

1. Press **MIN MAX** to step through the maximum (MAX), minimum (MIN), or the average (AVG) readings.
2. Press and hold **MIN MAX** to exit MIN MAX mode.

Using the Offset to Adjust for Probe Errors

Use the offset option in Setup to adjust the thermometer's readings to compensate for the errors of a specific thermocouple.

1. Plug the thermocouple into the input connector.
2. Place the thermocouple in a known, stable temperature environment (such as an ice bath or a dry well calibrator).
3. Allow the readings to stabilize.
4. In Setup change the offset until the display reading matches the debug temperature. (See "Changing Setup Options.")

Over Limit Alarm (Only UT323 and UT325)

Setting the low alarm and high alarm limit at the SETUP mode, the thermometer beeps when the measured temperature is higher or lower than the pre-set limit. (See "Changing Setup Options.")

Over Limit Signal Output (Only UT323 and UT325)

Setting the low and high limit signal output at the SETUP mode, the SIGN port output the corresponding signal when the measured temperature is higher or lower than the pre-set limit. (See "Changing Setup Options.")

Debug (Only UT323 and UT325)

After entering the Debug mode, you can self-debug. Follow the procedures as below:

- **Debug point:**
 - K- and J- type: -180°C, 0°C and 900°C
 - T type: -180°C, 0°C and 400°C
 - E type: -140°C, 0°C and 900°C
 - R- and S- type: 0°C and 1200°C
 - N type: -180°C, 0°C and 1200°C
 - Remark: 0°C is only for debugging K type.

- **Debug method:**

1. Connect T1 and T2 to standard voltage source.
2. Standard voltage source sources the voltage corresponding to debug point.
3. Press **HOLD** to freeze the debug data.
4. Normal Temperature debug:
Press **MAX MIN** when the thermometer is at Debug mode, secondary display 1 shows the offset reading.
Secondary display 2 shows the normal temperature.
Press **▲** or **▼** to adjust the offset reading, the offset range is -6~+6.

Remark:

For Temperature VS Voltage table, refer to BS EN 60584 - 1:1996. Before carrying out the debug, please ensure your standard source has the accuracy up to the demand. Our company will not be liable for massive deviation occurring to the accuracy of the thermometer that has been caused by improper selection of standard source on users' side.

Using Memory

During a logging session, the thermometer stores logged readings in its memory.

The thermometer stores 00-99, total 100 sets of temperature readings. The stored readings are from primary display.

Starting and Stopping Logging

1. Set the logging interval. (See "Changing Setup Options.")
2. Press **STORE** to start logging.
DATA shows and blinks on LCD.
3. Press **STORE** again to stop logging.
4. If you selected a manual logging interval, set the logging interval as 00:00. Press **ENTER** each time you want to store logged readings in memory. The secondary display 1 shows the logged reading. Each presses of **ENTER** will automatically store the logged readings in the next memory location. Press **▲** or **▼** could change the memory location, the empty location shows "- - - -".
5. If you selected an auto logging interval, set the logging interval to any time except 00:00. After entering logging mode, the secondary display 2 shows ":". Press **ENTER** to start storing readings in sequence according to the pre-set logging interval, the ":" blinks. Press **ENTER** again to pause auto logging, the ":" stop blinking. Press **ENTER** again to resume logging, the ":" blinks again.

Viewing Logged Readings

1. Press **RECALL** to view logged readings.
RCL shows and blinks on LCD.
2. Press **▲** or **▼** to scroll through the logged readings, the default reading is the last stored reading prior to exiting the logging. The temperature unit will switch automatically along with the recalled data based on what have been stored during the logging.
3. The secondary display 1 shows its memory location. The secondary display 2 shows the system time when the data was logged. The primary display shows each logged reading.
4. Press **ENTER** causes the readings to change more quickly until memory location reaches 99.

Clearing Memory

1. Press **STORE** to enter logging mode, DATA shows and blinks on LCD.
2. Press and hold down **STORE** for 2 seconds, the display shows CLR.
3. Press **ENTER** to delete all the logged readings from memory. It is not possible to delete the logged readings one by one.
The display then shows "----"

Communicating with a PC

You can transfer the data from the thermometer's memory to a PC using the included Software.

Press **SEND** button and USB blinks on the display. It means the Thermometer has already been communicated normally to the PC. Details refer to the Installation Guide file in the Software.

Under the influence of radiated Radio-Frequency electromagnetic Field the captioned models have a measurement error, it will be back to normal when the interference is removed.

Maintenance

Replacing the Battery

Replace the batteries as soon as the battery indicator  appears. The possibility of false readings can lead to personal injury.

1. Turn off the thermometer.

2. Loosen the screw and remove the battery door.
3. Replace the battery with a new 9V battery (6F22). Reinstall the battery door and tighten the screw.

Cleaning the Case

Clean the surface of the thermometer with soft cloth or sponge dampened with water or mild detergent. Do not get water inside the thermometer, otherwise it may cause damage to internal circuits or the instrument.

Specifications

Environmental

| | |
|-----------------------|--|
| Operating Temperature | -10°C to 50°C (14°F to 122°F) |
| Storage Temperature | -40°C to + 60°C (-14°F to +140°F) |
| Humidity | Non condensing <10°C (<50°F) 95% RH: 10°C to 30°C (50°F to 86°F) 75% RH: 30°C to 40°C (86°F to 104°F) 45% RH: 40°C to 50°C (104°F to 122°F) |

General

| | |
|---------------|---|
| Certification |  |
| Safety | EN61326: 2006, EN55022: 2006 and EM55024: 1998+A1+A2 |

Electrical

| Function | UT321 | UT322 | UT323 | UT325 | Input Protection | |
|----------------------|---|--------|---|--------|------------------|--|
| Type | K, J, T, E | | K, J, T, E, R, S, N | | 30V | |
| Input | T1 | T1, T2 | T1 | T1, T2 | | |
| Measurement Range | K type: -200.0°C to +1372°C (-328.0 °F to +2501 °F) J type: -210.0°C to +1200°C (-346.0 °F to +2192 °F) T type: -250.0°C to +400.0°C (-418 °F to +752.0 °F) E type: -150.0°C to +1000°C (-238.0 °F to +1832 °F) | | | | | |
| Display Resolution | 0.1°C °F/K.... (<1000) (T type below -200°C and R type, S type is 1°C °F/K) 1.0°C °F/K.... (>1000) | | | | | |
| Measurement Accuracy | ±(0.5%+0.8°C(1.6°F)) | | K-,J-,T-, E- type: ±(0.2%+0.6°C(1.2°F)) R,S type: ±(0.2%+2°C(4°F)) N type: ±(0.2%+1.5°C(3°F)) | | | |
| | Below -10°C: add 0.5°C Below -200°C, add +2°C Type T Below -200°C: for reference only. | | | | | |
| Sampling Rate | 50 times per second, Updates 2-3 times per second | | | | | |
| Time | Relative Time | | | | | |
| Data Store | 0 ~ 99 sets | | | | | |
| Setup | Logging Interval, Thermocouple Type, Offset (T1), Offset (T2) (UT322 and UT325 only), Sleep Mode, Line Frequency, Time, High/Low Limit (UT323 and UT325 only), Over Limit Signal Output (UT323 and UT325 only), Normal Temperature Compensation, Debug (UT323 and UT325 only) | | | | | |
| Over Limit Alarm | N/A | | Yes | | | |
| Over Limit Signal | N/A | | Yes | | | |
| Power | One piece of 9V (NEDA1604 or 6F22 or 006P) | | | | | |

Accuracy is specified for ambient temperatures between 18°C(60°F)and 28°C (82°F) for a period of 1 year, operating temperatures: -10°C ~ 50°C (14°F ~ 122°F). The above specifications do not include thermocouple probe error.

* END *

This operating manual is subject to change without notice.

UNI-T®
UNI-TREND TECHNOLOGY (CHINA) CO., LTD.

No6, Gong Ye Bei 1st Road,
Songshan Lake National High-Tech Industrial
Development Zone, Dongguan City,
Guangdong Province, China
Tel: (86-769) 8572 3888
http://www.uni-trend.com

说明书菲林做货要求:

| 序号 | 项目 | 内容 | |
|--------------|---|--|---------------------------------|
| 1 | 尺寸 | (297x346) ±1mm. 折叠成形尺寸: (99*173) ±1mm | |
| 2 | 材质 | 60g书纸 | |
| 3 | 颜色 | 黑色, 双面印刷 | |
| 4 | 外观要求 | 印刷完整清晰, 版面整洁. 无分层. 残损. 毛边等缺陷 | |
| 5 | 装订方式 | 297mm方向风琴折, 346mm方向对折, 封面图在外面 | |
| 6 | 表面处理 | 无 | |
| 7 | 其它 | | |
| 版本 | | REV.5 修改成股份有限公司 | |
| DWH 设计 | 黄荣伟2018.06.25 | MODEL 机型: UT320系列 | Part NO. 物料编号: 110401104391X |
| CHK 审核 |  |  优利德科技(中国)股份有限公司 UNI-TREND TECHNOLOGY (CHINA) CO., LTD. | |
| APPRO. 批准 |  | | |