

Ground Tester Software Quick Guide (V1.1)

1、 About This Manual

This Manual is about how to use the Software of the Ground Tester.

This software fixes the system of Microsoft Windows XP.

The function of the software:

- (1)、 Real-time monitoring .
- (2)、 Uploading historical data .
- (3)、 Wave drawing 、 maximum 、 minimize and average value indication.
- (4)、 Alarm setting.
- (4)、 Print and Save .

2、 Software Installation

Run the green version on your computer:

Step1: Put the disc in your CD-ROM.

Step2: Open the CD-ROM at the root list.

Step3: Copy “SetupFile\support” document to your hard disk C: or other disk.

Step4: Open “SetupFile\support” document and double click the icon



“ ” to run the software, and you can see the interface of the

software and then installation has finished.

Install the installation version on your computer:

Step1: Put the disc in your CD-ROM.

Step2: Open the CD-ROM at the root list.

Step3: Double click the icon of
software on your system.



run the wizard to install the

Step4: Follow the wizard step by step, after successful installation you can run the software
at the **Start-Program** menu.

3、 Quick Guide

Step1: Run the software as descript above at chapter 2.

Step2: Turn on the power of Ground Tester and connect it to PC COM port (DB9).

Step3: Setting the COM port at **Edit** menu **com setting**. (Figure 3-1)




Figure 3-1

Select the COM port you connected of your PC. (Figure 3-2)




Figure 3-2

Other parameters are default (Baud Rate: 9600 Databit: 8 Stop bit: 1 Parity: NONE).

If you do not know which port of your computer you connected, you can check the “[Device Manager](#)” list at [Control panel-System-Hardware-Device Manager](#) and then you can see the com port number at the tree list.

Step4: When you select the efficient COM port, the Communicate state will indicate “COM open success”. Underside will indicate “Tester link success” if you connect the Ground Tester right. And then you can read the real-time and the wave data on the screen, also you can select the [Recall](#) option and click [Read](#) button to upload the historical data from the Ground Tester and you can save as a report by clicking the [Save](#) button.

4、 Problem Shooting

(1)、 You can not run the software on your computer.

If you failed to try the two methods of chapter 2. There is a lack of your computer’s file in most cases. You can try to install the software on other computer or reinstall your system, or connect us for support.

(2)、 The software run success but can not connect to the Ground Tester.

You can check if your PC’s port is OK. When you use a USB-RS232 cable you must sure that the driver install right and the Baud Rate is supported by the cable. Check com setting is all right. Also you can see the Communicate State window and State Information underside to judge the problem.

(3)、 The software can not display all the interface on the screen.

This software is designed to use on color monitor larger than 17 inch. So you must use larger color monitor.

5、 More Information

Please read the << User Manual >>of Ground Tester carefully or contact us for support.